



HELPFUL HINTS & RECOMMENDATIONS FOR SAFE OPERATION WHEN TOWING YOUR TRAILER

CHECKLIST AND PROCEDURES TO BE CARRIED OUT BEFORE MOVING OFF

- Ensure coupling is connected properly.
- Check tyre pressure
- Release hand brake if fitted, and reversing latch.
- Raise jockey wheel (if fitted)
- Attach safety chains to tow vehicle.
- Plug in wiring loom.
- Test operation of all lights.

Regular Maintenance

- Check tyres for wear and pressure.
- Check spare wheel is secure and inflated to correct pressure.
- Check wheel nuts are tight and check bearing end play.
Check coupling bolts, check spring bolts, and 'U' bolts.
Are all secure?
- Check brake fluid level. If low check for leaks.

Loading of Trailer

- Ensure weight of load is distributed evenly over axle/s.
- Check load is secure and tied down
- Check winch is locked (Boat trailers)
- Check bow safety chain is fastened securely (Boat trailers)
- Check all transom tie downs (Boat trailers)
- Check weight distribution (Boat trailers)

REMEMBER: SAFETY MEANS REGULAR INSPECTIONS

MAINTENANCE: Refer trailer information booklet

**Important – new trailers should have wheel nuts and bearing end play
checked at 20km & 100km.**

223 COLCHESTER RD, KILSYTH, VIC 3137
P.O. Box 223, Kilsyth VIC 3137
PH: (03) 9761 5533 FAX: (03) 9761 5465
Email: sales@trailerfactory.com.au
WEBSITE: www.trailerfactory.com.au
